



# PEX Go/No-Go Gauge




1. Slide the correct slot on the gauge around the crimped ring.



2. If the ring does not fit into the slot at all, then the crimp is a "No-Go". Adjust the crimping force on the tool and re-crimp the ring.



3. If the ring slides into the slot and stops in the "Go" range at least at one point, then the crimp is good. The ring will not fit the go range all the way around it.



4. If the ring slides all the way into the slot, then the crimp ring is compressed too small and is a "No-Go". Remove the ring and adjust the crimping force on the tool.

